


5BR™



## 5BR™

### Replacement Parts

No.	Part No.	Description	Part No. Includes*
<b>1**</b>	RA-C1	Motor - Mono Phase 0,37KW	1
	RA-C3	Motor - Tri Phase 0,37KW	1
	RA-D1	Motor - Mono Phase 0,55KW	1
	RA-D3	Motor - Tri Phase 0,55KW	1
	RA-E1	Motor - Mono Phase 0,75KW	1
	RA-E3E2	Motor - Tri Phase 0,75KW	1
	RA-F1	Motor - Mono Phase 1,10KW	1
	RA-F3E2	Motor - Tri Phase 1,10KW	1
<b>2</b>	R070430	Bolts	4
<b>3</b>	RC3121D	Seal Plate (0,25KW - 0,37KW)	1
	RC3122D	Seal Plate (0,55KW -> 1,10KW)	1
<b>4</b>	RU10993SS	Mechanical Seal	1
<b>5</b>	RU9169	O-Ring	1
<b>6</b>	RC105117PBD	Impeller 0,25KW Mono & Tri Phase	1
	RC105117PD	Impeller 0,37KW Mono Phase	1
	RC105117PDA	Impeller 0,37KW Tri Phase	1
	RC105138PD	Impeller 0,55KW Mono Phase	1
	RC105138PDA	Impeller 0,55KW Tri Phase	1
	RC105137PBB	Impeller 0,75KW Mono Phase	1
	RC105137PBBA	Impeller 0,75KW Tri Phase	1
	RC105137P	Impeller 1,10KW Mono Phase	1
	RC105137PA	Impeller 1,10KW Tri Phase	1
<b>7***</b>	RC3012	Impeller Lock Screw	1
<b>8</b>	RL125P21	Diffuser 0,25KW - 0,37KW	1
	RC1200P	Diffuser 0,55KW -> 1,10KW	1
<b>9</b>	RU30542SS	Screws & Washers	3
<b>10</b>	RL211	Diffuser Ring 0,25KW - 0,37KW	1
	RC2110	Diffuser Ring 0,55KW -> 1,10KW	1
<b>11</b>	RC7645DWB	Pump Body & Drain Plugs	1
<b>12</b>	RU21268T	Drain Plugs	2
<b>13</b>	RC10833P	Basket	1
<b>14</b>	RU9161	O-Ring	1
<b>15</b>	RC3140DC	Lid	1
<b>16</b>	RC15418D	Lock Handle Lid	2
	PP5000	Seal Set (Partn° 4, 5, 10, 14)	

\* PART NUMBER INCLUDES REQUIRED QUANTITY PER PRODUCT

\*\* SEE MOTOR SHEET FOR MOTOR SPARE PARTS

\*\*\* IMPELLER SCREW ONLY ON TRI PHASE PUMPS